













Table with columns: Charges permanentes (DaN/m²), Classe de résistance, Nb pannes/versant, Largeur panne (mm), and various resistance values (W, Mode, W, Mode, W, Mode, W, Mode) for different configurations.